




CHAISELONG

WITH ARMREST






MODULAR SOFA


I

A	6	
B	12	Plastic 
C	6	No. 152 2.5 cm 

II



III




IMPORTANT



The direction in which the hooks are connected, goes from left to right.
At least two people are necessary to lift the sofa, do not lift the sofa alone or push it.
It may cause damage in the connecting mechanisms and may create creaking noise in furniture.
The sofa has to be placed on a flat and leveled surface.
While attaching parts make sure hooks No. 1 fit with hooks No. 2.

VILMERS




CORNER




I

A	4	
B	8	Plastic 
C	4	No. 152 2.5 cm 

II



III




IMPORTANT

The direction in which the hooks are connected, goes from left to right.
At least two people are necessary to lift the sofa, do not lift the sofa alone or push it.
It may cause damage in the connecting mechanisms and may create creaking noise in furniture.
The sofa has to be placed on a flat and leveled surface.
While attaching parts make sure hooks No. 1 fit with hooks No. 2.

VILMERS



SEATER

WITH ARMREST






MODULAR SOFA


I

A	4	
B	8	Plastic 
C	4	No. 152 2,5 cm 

II



III



IMPORTANT

The direction in which the hooks are connected, goes from left to right.
At least two people are necessary to lift the sofa, do not lift the sofa alone or push it.
It may cause damage in the connecting mechanisms and may create creaking noise in furniture.
The sofa has to be placed on a flat and leveled surface.
While attaching parts make sure hooks No. 1 fit with hooks No. 2.

VILMERS