





SEATER


WITH ARMRESTS



I


A	4	 Plastic
B	4	 M8
C	2	 No. 244 6 cm

II



III

Attach parts of the sofa




IMPORTANT

The direction in which the hooks are connected, goes from left to right.
At least two people are necessary to lift the sofa, do not lift the sofa alone or push it.
It may cause damage in the connecting mechanisms and may create creaking noise in furniture.
The sofa has to be placed on a flat and leveled surface.
While attaching parts make sure hooks No. 1 fit with hooks No. 2.

VILMERS


CORNER



I


		M8
A	4	
B	4	No. 245 6 cm
C	4	Plastic
D	4	
E	4	M6
F	4	Metal

II



III

Attach parts of the sofa




IMPORTANT

The direction in which the hooks are connected, goes from left to right.
At least two people are necessary to lift the sofa, do not lift the sofa alone or push it.
It may cause damage in the connecting mechanisms and may create creaking noise in furniture.
The sofa has to be placed on a flat and leveled surface.
While attaching parts make sure hooks No. 1 fit with hooks No. 2.

VILMERS




SEATER

WITH ARMRESTS




MODULAR SOFA

I


A	4	 Plastic
B	4	 M8
C	2	 No. 244 6 cm

II



III

Attach parts of the sofa



IMPORTANT

The direction in which the hooks are connected, goes from left to right.
At least two people are necessary to lift the sofa, do not lift the sofa alone or push it.
It may cause damage in the connecting mechanisms and may create creaking noise in furniture.
The sofa has to be placed on a flat and leveled surface.
While attaching parts make sure hooks No. 1 fit with hooks No. 2.

VILMERS