


SIN
DIG



VÆRØY
MØBELTREKK

320393/320394



Solide håndtak i alle hjørner gjør det enkelt å ta av og på trekket.



2 innstramminger per sidevegg gjør det mulig å tilpasse trekket til møblene.



Kraftige hemper i alle hjørner, sikrer at trekket holdes på plass ved kraftig vind.



4 lufteventiler med avstivet åpning og meshforing sørger for god gjennomlufting og hindrer kondens.



ADVARSEL!

- **DETTE ER IKKE ET LEKETØY. HOLD BARN PÅ AVSTAND!**
- **SØRG FOR LUFTING.** For å skape god ventilasjon og unngå kondens, ikke dra møbeltrekket helt ned til bakken!
- **KONTROLLER AT VANN IKKE BLIR LIGGENDE PÅ SØMMENE.** Over tid vil vannansamlinger trenge gjennom sømmene og skade møbeltrekket og møblene under.
- **FARGEN KAN BLEKNE I SOLLYS.** Dette påvirker ikke produktets funksjon.
- **PUTER OL MÅ IKKE LAGRES UNDER MØBELTREKKET!** I fuktig vær kan det dannes jordslag som kan ødelegge putene. Puter bør lagres innendørs.
- **PASS PÅ AT HAGEMØBLER OG ANNET SOM PLASSERES UNDER TREKKET, ER TØRT.** Dersom møblene er fuktige når trekket legges på, kan det dannes mugg og jordslag på møblene.
- **UNNGÅ VANNANSAMLINGER PÅ MØBELTREKKET** ved å lage et høyt punkt midt på trekket, f.eks med en pinne eller en bøtte under møbeltrekket. Da oppstår en naturlig drenering, og vannet renner bort fra møbeltrekket. Unngå at møbeltrekket får et flatt "tak" slik at vannansamlinger dannes. Over tid, vil vann trenge gjennom sømmene eller fryse til is og ødelegge møbeltrekket.
- **SØRG FOR MINIMAL KONTAKT MELLOM OVERTREKKET OG MØBELET** SLIK AT DET ER GOD SIRKULASJON. Hvis trekket blir liggende flatt mot f.eks bordplaten, vil det kunne oppstå en reaksjon mellom trekket og møbelet.
- Trekket må ikke tas på hvis møblene er varme da dette kan skape en reaksjon på trekket eller møbelets overflate.
- Trekket må være tørt før det lagres i bæresesken.


VEDLIKEHOLD

- Rengjøres med en fuktig klut, eller børstes med en myk kost.
- Når trekket ikke brukes, brett det pent sammen og legg det flatt til lagring.
- Pass på at trekket er helt tørt før lagring.

Produsert i Kina for Bohus AS
Østre Aker vei 19, 0581 Oslo
www.bohus.no

Forbrukerkontakt: Nordic Season Products AS,
Kjeller Vest 3, 2007 Kjeller, Norge
www.nordicseason.no

SIN
DIG



VÆRØY

FURNITURE COVER

320393/320394



Sturdy handles in all corners make it easy to put the cover on and off.



2 tightenings on each side make it possible to adapt the cover to any furniture.



Strong loops in all corners ensure that the cover stays in place in strong winds.



4 ventilation valves with a reinforced opening and mesh lining ensure good ventilation and prevent condensation.



WARNING!

- **THIS IS NOT A TOY. KEEP CHILDREN AT A DISTANCE!**
- TO KEEP GOOD VENTILATION AND AVOID CONDENSATION, do not pull the furniture cover all the way down to the ground.
- MAKE SURE THE SEAMS ARE NOT COVERED WITH COLLECTED WATER. Gradually, water will penetrate through the seams and damage the cover and furniture.
- WHEN THE COVER IS EXPOSED TO SUNLIGHT, THE COLOR MAY FADE. This will not affect the functionality of the cover.
- DO NOT STORE CUSHIONS OR PILLOWS UNDERNEATH THE COVER. Indoor storage for fabric cushions is recommended.
- ENSURE THAT FURNITURE AND THE LIKE ARE DRY BEFORE PUTTING THE COVER ON. If the furniture is wet when pulling the cover on, mildew can occur.
- Preventing water collecting or pooling on your furniture cover is best achieved by providing a support pole underneath the cover, to push the water out. This will create a natural drainage and redirect water away from the cover. Although the seams are stitched, if water is allowed to collect and sit for long periods, some seeping through can occasionally occur. Avoid a "flat roof" shape of the cover, as water can penetrate through the seams and freeze to ice and can cause serious damage to the cover.
- ENSURE MINIMAL CONTACT BETWEEN THE COVER AND THE FURNITURE SO GOOD CIRCULATION IS OBTAINED. If the cover is laid flat against e.g. tabletop, a reaction between the cover and furniture may occur.
- Do not put the cover on if the furniture are heated due to sunlight, as this can cause a reaction between cover and furniture.
- The cover must be dry before it is stored in the bag.

MAINTENANCE

- Clean the furniture cover with a soft-bristle broom, or wipe with a wet cloth.
- Fold the cover neatly and store it flat, when not in use.
- Make sure the furniture cover is dry before storing it away.

Made in China for Bohus AS
Østre Aker vei 19, 0581 Oslo
www.bohus.no

Consumer contact: Nordic Season Products AS,
Kjeller Vest 3, 2007 Kjeller, Norge
www.nordicseason.no